


## How to Properly Uninstall Version 12 Driver


1. Go to Applications > HuionDriver > double click TabletDriver Uninstall
2. On the pop-up box, click “Uninstall Driver” (you may need to enter your password to execute this process)

## How to Install Version 12 Driver


1. Locate your driver installation package folder and double click on it.
2. Click close after the driver installation is complete.




3. Double click on the driver installation package again and click “Continue”.




- Click "Install".




- Enter your computer password again, then click "Install Software".




- Click "OK" on the pop-up box.




7. Make sure that the tablet driver shows “Device Connected” then Click “Open System Preferences”.




8. On the Input Monitoring setting, make sure to check the “TabletDriver” app. (If you don't see any Input Monitoring setting, you can skip this step and proceed to Step #11 below.)




9. Then click “Quit & Reopen”.



10. Tap your digital pen on your tablet’s surface and click on “Open Systems Preferences on the pop-up box.



11. On the Accessibility settings, make sure to check the “TabletDriver” app.



12. Your tablet driver will temporarily show as disconnected as your computer updates the settings. Once done, your tablet driver will then show “Device connected” and your driver is now successfully installed.

